LASVIT SPACEY FLOOR LAMP MANUAL CE

by Lukáš Novák



FN

Contents

Warnings	1
Technical parameters	2
Step-by-step installation	3
Light source replacement	6
Warranties and Warranty Terms and Conditions	7

Markings

Warns you of high risk of damage to the fixture or injury.

🖄 Risk of electrical injury.

Warns you of high risk of electrical injury should a live part be directly or indirectly touched.



Warns you about possible damage to the fixture.



i Important


ote

Important information regarding the usage of your fixture.

Gives you general information about the usage of your fixture.

Please read this manual carefully and keep it in case you need assistance while performing maintenance and cleaning procedures.

1/ Warnings



Warns you of high risk of electrical injury should a live part be directly or indirectly touched.

• Before starting any procedures make sure that the power to the lighting fixture is switched OFF and secured against unauthorized, negligent or accidental switching on.

Warns you of high risk of damage to the fixture or injury.

• Installation and electrical wiring should be carried out by a qualified electrician to prevent any damage to health or property.

• This lighting fixture is to be mounted on fire proof surfaces.

• For indoor use only! Dry location only.

• The manufacturer shall not be held liable for any defects caused by unqualified handling of the lighting fixture.

 Lasvit shall not be held liable for any injuries or damage to the fixture or other property caused during installation or by improper fixing.

i Important

Important information regarding the usage of your fixture.

- Installation requires 1 person.
- Fixing material is not part of the lighting fixture kit.

• To retain quality of hand-blown glass, Lasvit recommends to cleaning the glass at least every 3 months, please see Product care manual.

• Proper fixing is the responsibility of the customer.

 The light sources changeable by the customer are provided as a reference gift.




Never dispose of this product in mixed municipal waste, it must be submitted at the designated disposal installation.


2/ Technical parameters

Item ID / Spacey CL094FA-1CE Light source / 1 x E27, max 20W Input voltage / 220–240V, 50/60Hz Rated power / max. 20W Protection rating / IP 20 Safety class / CLASS II Dimensions / Dia 350x 498mm Weight / approx. 8 kg


3/ Step-by-step installation


Step 1





Step 4





Screw the bulb in the socket clockwise. Use E27 bulb with the following specifications: max. 20W, 220–240V. The manufacturer shall not be held responsible for improper function when other light source is used.

Plug in the lamp to the power grid and switch it on.

4/ Light source replacement

earrow Before starting installation make sure the power to the lighting fixtureis switched OFF and secured against unauthorized, negligent or accidental switching on.

ightarrow Replacement of the bulb should be carried out by qualifed technician to prevent damage to health or property.

The manufacturer shall not be held responsible for injuries, damage to the fixture and/ or other property when other than specified light source type and/ or rating is used.



All light sources can be supplied by the manufacturer, Lasvit s.r.o.

Lasvit provides NO warranty on bulbs and is not responsible for any damage or injury caused during its installation or during its operation.

5/ Warranties and Warranty Terms and Conditions

- The warranty is defined in Price Quotation (PQ) or in Purchase Agreement (PA). If not stated otherwise, the warranty shall not cover the light sources, maintenance, service and cleaning and the standard warranty shall be set at 2 years. Any other warranties must be specified in PQ or PA. The Customer must submit a valid agreement, invoice or another payment document as a base for any complaint.
- 2. If the warranty covers the detected defect, the Customer shall inform Sales (by e-mail or phone, defining the project / product number, the project / product name, the areas where the defect has emerged, and the sketch number. The Customer shall describe the defect).
- Sales shall proceed based on the internal guideline for complaint management.
- 4. The Manufacturer shall analyze the origins of the defect either at the Customer's or at the Manufacturer's, after the defective product has been delivered to the Manufacturer's premises.
- After the analysis, the decision about acknowledgement or refusal of the complaint and the respective explanation shall be passed on to Sales.
- 6. Sales shall submit information about acknowledgement / refusal of the complaint to the Customer within 7 workdays from reporting the defect at the latest. Sales shall agree further steps with the Customer (e.g. the date of repair, replacement, etc., based on the Customer's and Manufacturer's capacities). Unless agreed otherwise, the Manufacturer shall eliminate any defect within 30 days from the date of submittal of the complaint.
- 7. The complaints shall not cover any defects caused by the Customer, normal wear and tear, or by failure to follow the service manual or installation manual. The complaints shall not cover any defects caused by force majeure.
- 8. The analysis may lead to the following conclusions:

Manufacturer's fault:

- The product is repairable at the Customer's at the Manufacturer's cost.
- The product is repairable at the Manufacturer's at the Manufacturer's cost.
- The product is not repairable and shall be replaced by a tested functional one at the Manufacturer's cost.
- The product is not repairable and the Manufacturer cannot offer any replacement. The Manufacturer shall offer another product. The Customer shall accept the offer and settle the new product by a difference payment, or the Manufacturer shall pay a difference payment to the Customer.
- The product is not repairable and the Manufacturer cannot offer any replacement. The Manufacturer shall issue a refund to the Customer.

Customer's fault:

- The product is repairable at the Customer's at the Customer's cost.
- The product is repairable at the Manufacturer's at the Customer's cost.
- The product is not repairable and shall be replaced by a verified and functional one at the Customer's cost.
- The product is not repairable and the Manufacturer cannot offer any replacement. The Manufacturer may offer another product for purchase.

Lasvit s.r.o. / Komunardů 32 / 170 00 Praha 7 / Czech Republic T +420 481 120 810 / F +420 481 120 622 / E lasvit@lasvit.com lasvit.com In case you need any assistance or have any suggestion, please contact us at



© LASVIT s.r.o. / Komunardů 894/32 170 oo Prague 7 / Czech Republic